


7

小车复位 small bus reset


•



click  button, small bus reset



8

Install the cylindrical fixture







9


# 安裝的工件尺寸 Dimensions

- Capable of printing media with a length of 600mm and a diameter of 20~110mm.




10

Color white print workpiece reference size




11

Colour print workpiece reference size



12

White print workpiece reference size






## 打印图片

1


通过  按钮调整介质高度 Adjust the media height with the button **up down**



2

喷头到打印介质距离 Distance from printhead to print media

- In the Print Control Centre software, click the button **left** to slowly move the small bus to the media being printed, and reconfirm that the distance from the printhead to the media is within 1.5 mm.



3

Reset the small bus •

Click the button  Small bus resets